



PARTS LIST

<p>1A575 1/4" SOLENOID VALVE</p> 	<p>2F985 PNEUMATIC VALVE FOR REVERSER</p> 	<p>REVERSER</p> 	<p>PLC PLC CONTROL</p> 
<p>388 RELAY</p> 	<p>782 RELAY</p> 	<p>FLOWMETER COMPLETE WITH FITTINGS</p> 	<p>FLOWMETER GLASS GLASS ONLY</p> 
<p>388 SOCKET</p> 	<p>782 SOCKET</p> 	<p>HOUR METER</p> 	<p>RS1044 CLEAN OUT SWITCH</p> 
<p>SAFETY TEMP SWITCH</p> 	<p>HS16IN ROTARY SWITCH</p> 	<p>120/240DGTMP TEMP CONTROLLER</p> 	<p>3XC59 PUMP SWITCH</p> 
<p>2A148 PRESSURE GAUGE</p> 	<p>6Z955 1/4" MINI AIR REGULATOR</p> 	<p>L057800 DRIVE SHAFT</p> 	<p>PSHIGH PRESSURE SWITCH</p> 

<p>4SCREEN</p> 	<p>6SCREEN</p> 	<p>4PT 4" PRE-FILTER</p> 	<p>6PT 6" PRE-FILTER</p> 
<p>HF4SPATE RESERVOIR SLEEVE PLATE</p> 	<p>HF49GPM - 4 & 9 GALLON RESERVOIR SLEEVE</p> 	<p>HF4GPM - 4 GALLON HF9GPM—9 GALLON RESERVOIR SLEEVE</p> 	<p>RF RESERVOIR FILTER (DISCONTINUED, REPLACE WITH HF4GPM, HF9GPM OR HF49GPM)</p> 
<p>14OILSWE 1/4 OIL SWIVEL ELBOW</p> 	<p>1814QC 1/8 x 1/4 QUICK CONNECT</p> 	<p>14QCS 1/4 QUICK CONNECT STRAIGHT</p> 	<p>14QCT 1/4 QUICK CONNECTOR RUN</p> 
<p>14QCSWE 1/4 QUICK CONNECTOR SWIVEL ELBOW</p> 	<p>BIG CLIP</p> 	<p>SMALL CLIP</p> 	<p>3XC64 CIRCUIT BREAKER</p> 
<p>COMP 7</p> 	<p>POWER CORD</p> 	<p>PUMP & MOTOR 051C623119</p> 	